

euTotech


ASSEMBLY INSTRUCTION


Remove all items from the carton . Verify all pieces before assembly.


KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION
1	5	Caster	8	2	Armrest	13	1	Hex Nut 10mm
2	1	Base	9	2	Arm Width Adjustment Knob + Washers	14	1	Plastic Cover
3	11	Seat Post				15	1	17mm Allen Wrench
4	1	Seat	10	4	Mechanism Bracket Screw 8x25mm+Washer	16	1	M5 Size Allen Wrench
5	1	Mechanism				17	1	M6 Size Allen Wrench
6	4	Mechanism Screw 6x24mm	11	1	Backrest			
7	2	Arm Bracket	12	1	Security Screw 10x205mm	1		











MECHANISM INSTRUCTIONS:

- (A) Pneumatic seat height adjustment: Lift to adjust seat height.
- (B): Tilt tension micro adjustment knob : Slightly turn clockwise to increase tilt tension and counter - clockwise to decrease.
- (Pull knob (B) out for easy operation)
- (C) Backrest locking control knob: Turn clockwise to lock backrest in position and counter - clockwise to unlock.
- (Pull knob (C) out for easy operation) (D): Seat slide control lever :
- Lift lever up to slide and release once desirable position is reached.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
 DO NOT USE THIS CHAIR AS A STEP STOOL / LADDER.
 DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
 DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
 DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS
- ARE TIGHTENED.
 EVERY SIX MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS
 AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.

- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS. DISPOSE OF PACKAGING PROPERLY. PLASTIC BAG IS NOT A TOY, DO NOT USE PLASTIC BAG AS HEAD COVERING IT MAY CAUSE SUFFOCATION. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY. NOTE:SOME SCREWS MAY BE PREASSEMBLED. IF PREASSEMBLED, IGNORE
- ASSEMBLY INSTRUCTIONS PLEASE KEEP THIS PAGE FOR FUTURE REFERENCE.