model no:

LR305P, LR305R

ACCESSORIES

32 GAL. DOOR RECEPTACLES



(C) Wabash Valley Manufacturing, Inc.

customer service:

ASSEMBLERS: If you find any parts missing or damaged, or if you're having difficulty assembling your furniture/equipment, call us at:

* Before calling, have your product model number available.

1-800-253-8619 (Inside U.S.A.) 260-352-2102 (Outside U.S.A.)

Monday thru Friday, 8:00 AM - 4:30 PM Eastern Time (EXCEPT HOLIDAYS)

Any correspondence concerning our product should be sent directly to our Customer Service Manager at:

Wabash Valley Manufacturing, Inc. 505 E. Main Street P.O.Box 5 Silver Lake, IN 46982 U.S.A. FAX: 260-352-2160

maintenance:

Regular inspection and maintenance of all parts, and fasteners is necessary. Tighten all bolts and nuts. Inspect Tops, Seats, Legs, Braces and Fasteners periodically for wear or vandalism. Replace broken or worn parts immediately or take equipment out of service until repairs are made. Use genuine Wabash Valley replacement parts.

To restore plastisol coating to its luster after prolonged use, wash/rinse/dry and use Armor—All 🕲 or similiar quality vinyl protectant.

KEEP THIS ASSEMBLY/SPECIFICATION SHEET FOR FUTURE REFERENCE.

specifications:

NOTE: We reserve the right to change specifications without notice.

Heat fused poly—vinyl coating, finished on inner—metal structure, to an approximate 3/16" thickness. Framework assemblies are finished with powder coating; electrostatically applied and oven cured according to powder manufacturer's specifications. Fasteners are stainless steel to resist corrosion.

TRASH RECEPTACLES:

Rib panel is 10 gage and perforated panel is 12 gage sheet metal. A 3/4" diameter steel tube is used to add support at the top and bottom. The door panels are 12 gage sheet metal. The bottom is 14 gage sheet steel.

GROUND SPACE REQUIRMENTS:

Ground space requirments are 25 3/8" diameter x 34 7/8" — Perf and 34 1/2" — Rib, tall. With door open to remove liner the width is 36 3/8". If a leg is used the height will be an additional 6".

HDS:

FT100N and FT110N consist of 18 gage steel. FT100N overall diameter is 22 7/8" and 1 3/4" tall with opening of 8" diameter. FT110N overall diameter is 22 7/8" and 1 3/4" tall with opening of 14" diameter. AL100N is a cast aluminum ash and trash lid.


DT100N consist of 3/16" thick injection molded structural thermo plastic. Dome is 10" high x 18" in diameter. Hole opening is 10" x 7 1/2" with spring loaded swing type door. The base is 22 3/4" in diameter with a skirt length of 1 5/8".


SB100N and AB100N consist of FT100N top with solid bonnet or ash tray on it. TB100N consist of FT110N top with tray return, made of 14 gage galvaneal. The shelf is 14" deep, 18" wide and is 8" above the flat top. Trim material is flexible embossed vinyl metal core.

LEG PACKAGES:

Leg packages LR100N and LR105N consist of 2 3/8" od x 12 gage galvanized structural steel tubing and use 14 gage sheet steel for the mounting plate and gussets to add support. The surface mount leg uses 1/4" plate steel for its surface mount plate.

Al318 page






$assembly \ procedures:$ IMPORTANT: Assemblers should be reasonably skilled in the assembly of commercial grade/heavy duty fabricated steel equipment.


To ensure proper assembly, it is suggested that you take adequate time to locate and identify each part. To prevent scratching of the finished pieces, we recommend this unit to be assembled on a clean, flat, solid, surface with a drop cloth, allowing plenty of working room. Also please read the instructions and study the sketches very carefully. A little extra time spent before assembly will be well worth it in performing a complete, proper assembly. Please note that all parts have been precut and pre-drilled.

During the assembly process leave all bolts and nuts "finger tight", until the entire unit is completely assembled. This allows room for movement to level or adjust all seats, tops, benches, framework and braces if necessary.


After final adjustment and leveling, permanently tighten all nuts, bolts and fasteners.





installation: WARNING: The proper installation for Wabash Valley products may depend upon many factors unique to the site, location, or use of a particular product. Consult with your contractor or other professional to determine your specific installation requirements.




parts identification/product dimensions:










assembly procedures, cont'd:

LATCH PIN ASSEMBLY



STEP 1: Rotate receptacle door to closed position; striker arm makes contact with trash receptacle. Open latch pin (Q), engage pin into holes on trash receptacle and close latch pin. See FIG. 2.




FIG. 3